

FYPON

STEWART ADJUSTABLE GABLE PEDIMENT KIT ASSEMBLY INSTRUCTIONS

TOOLS & MATERIALS REQUIRED

TOOLS

Tape Measure
Saw
Caulk Gun
Pencil
Safety Glasses
Framing Square
Cordless Drill
#2 Phillips Driver
#2 Phillips Screw Driver
Torpedo Level

MATERIALS

Wood Filler
Sand Paper (220 grit)

IMPORTANT NOTES AND ADDITIONAL INFORMATION

- It is highly recommended that safety glasses be worn during installation.
- Read the assembly instructions completely before beginning the assembly of the gable pediment.

PARTS SUPPLIED

DESCRIPTION

PL PREMIUM ADHESIVE
1 1/2" LONG SCREW


QUANTITY

1
5

ASSEMBLY INSTRUCTIONS


STEP 1

BEFORE CUTTING THE GABLE PEDIMENT, THE PITCH OF THE ROOF MUST BE DETERMINED. ONE METHOD OF DETERMINING THE PITCH IS BY USING A FRAMING SQUARE AND TORPEDO LEVEL. PLACE THE FRAMING SQUARE ALONG THE EDGE OF THE ROOF LINE WITH THE 12" (INCHES) MARK AT THE LOCATION SHOWN IN FIG.1. USE THE TORPEDO LEVEL TO LEVEL THE FRAMING SQUARE. ONCE THE FRAMING SQUARE IS LEVEL, READ THE DIMENSION ON THE TONGUE OF THE FRAMING SQUARE. IN THE SAMPLE SHOWN IN FIG.1 THAT DIMENSION IS 6" (INCHES). THE PITCH OF THE ROOF IS THEREFOR A 6/12 (RISE/RUN) PITCH.



STEP 2

AFTER DETERMINING THE PITCH, CUT THE RIGHT AND LEFT SIDE PIECES AT THE CORRESPONDING MARKING. FOR EXAMPLE: IF THE PITCH IS 6/12 YOU CUT ON THE 6/12 MARK ON THE RIGHT AND LEFT PIECES.



STEP 3

APPLY A 1/4" BEAD OF PL PREMIUM ADHESIVE, USING A CAULK GUN, TO THE ENDS OF PIECES JUST CUT.
JOIN THE LEFT AND RIGHT SIDE PIECES TOGETHER USING A 1 1/2" SCREW SUPPLIED, AS SHOWN IN FIG. 2.







FIG. 2




STEP 4

APPLY A 1/4" BEAD OF ADHESIVE, USING A CAULK GUN, ON THE LEFT AND RIGHT SIDE TABS AS SHOWN IN FIG. 3.



STEP 5

LAY THE CENTER PIECE ON THE LEFT AND RIGHT SIDE TABS, WHERE ADHESIVE WAS PREVIOUSLY APPLIED, AND ROTATE THE CENTER PIECE UNTIL IT LOOKS STRAIGHT. SEE FIG. 4 BELOW. NOTE: THERE IS A MARK ON TOP AND BOTTOM OF THE CENTER PIECE TO AID IN THE POSITIONING.



STEP 6

TURN THE PIECES OVER TO EXPOSE THE BACK OF THE GABLE PEDIMENT. USE FOUR (4) 1 1/2" SCREWS SUPPLIED TO ATTACH THE CENTER PIECE TO THE LEFT AND RIGHT AS SHOWN IN FIG. 5. NOTE: MAKE SURE TO PULL THE LEFT AND RIGHT SIDES TIGHT AGAINST THE CENTER PIECE BEFORE SCREWING TOGETHER. THE GABLE PEDIMENT IS NOW READY TO INSTALL.

